



A signal strength test will help you to find the best location for your antenna. This can be done on your phone, using an app or with a dedicated device. Make sure to check the correct network technology (2G for devices installed before 2024 or 4G & 2G otherwise). 3 or 4 bars on a 4-bar display would be recommended.

The antenna has a self-adhesive back, to allow you to secure it to a surface quickly and easily. Clean the surface before securing the antenna and make sure the location and surface are suitable.

- ✗ Metal Surface
- ✗ Electrical Noise



In areas with good signal strength, the antenna can be mounted within the VOLO cabinet. We recommend locating it away from the internal PSU to minimise any electrical noise interference.

The VOLO antenna should be mounted vertically with the cable coming out horizontally, as shown. Connect the antenna to the modem to finger tightness and no more.

